

Huawei FusionServer Pro 2298 V5 Server V100R005

Technical White Paper

Issue 01
Date 2019-10-30



Copyright © Huawei Technologies Co., Ltd. 2020. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions



HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: <https://e.huawei.com>

About This Document

Purpose

This document describes the 2298 V5 rack server in terms of features, structure, specifications, and component compatibility.





Intended Audience


This document is intended for:

- Huawei presales engineers
- Channel partner presales engineers
- Enterprise presales engineers

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.

Symbol	Description
 NOTE	Supplements the important information in the main text. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

Change History

Issue	Date	Description
01	2019-10-30	This issue is the first official release.

Contents

About This Document	ii
1 Overview	1
2 Features	2
3 Physical Structure	5
4 Logical Structure	6
5 Hardware Description	8
5.1 Front Panel.....	8
5.1.1 Appearance.....	8
5.1.2 Indicators and Buttons.....	9
5.1.3 Ports.....	12
5.2 Rear Panel.....	12
5.2.1 Appearance.....	13
5.2.2 Indicators.....	13
5.2.3 Ports.....	15
5.3 Processor.....	17
5.4 Memory.....	18
5.4.1 Memory Identifier.....	18
5.4.2 Memory Subsystem Architecture.....	19
5.4.3 Memory Compatibility.....	20
5.4.4 Memory Installation Guidelines.....	22
5.4.5 Memory Installation Positions.....	22
5.4.6 Memory Protection Technologies.....	24
5.5 Storage.....	24
5.5.1 Drive Configurations.....	24
5.5.2 Drive Numbering.....	25
5.5.3 Drive Indicators.....	28
5.5.4 RAID Controller Card.....	31
5.6 Network.....	31
5.6.1 LOMs.....	31
5.6.2 OCP 2.0 Mezzanine Cards.....	34
5.7 I/O Expansion.....	35

5.7.1 PCIe Cards.....	35
5.7.2 PCIe Slots.....	35
5.7.3 PCIe Slot Description.....	36
5.8 PSUs.....	37
5.9 Fans.....	38
5.10 Boards.....	39
5.10.1 Mainboard.....	40
5.10.2 Drive Backplane.....	42
6 Product Specifications.....	44
6.1 Technical Specifications.....	44
6.2 Environmental Specifications.....	48
6.3 Physical Specifications.....	50
7 Software and Hardware Compatibility.....	51
8 Safety Instructions.....	52
8.1 Safety Instructions.....	52
8.2 Maintenance and Warranty.....	55
9 System Management.....	56
10 Certifications.....	58
A Appendix.....	59
A.1 Product SN.....	59
A.2 Operating Temperature Limitations.....	60
A.3 RAS Features.....	60
A.4 Sensor List.....	62
B Glossary.....	68
B.1 A-E.....	68
B.2 F-J.....	69
B.3 K-O.....	69
B.4 P-T.....	69
B.5 U-Z.....	70
C Acronyms and Abbreviations.....	71
C.1 A-E.....	71
C.2 F-J.....	72
C.3 K-O.....	73
C.4 P-T.....	74
C.5 U-Z.....	76

1 Overview

Huawei FusionServer Pro 2298 V5 (marked as H22S-05 on the nameplate, 2298 V5 for short) is a new-generation 2U 2-socket rack server designed for Internet, enterprise, and telecom applications.

The 2298 V5 applies to distributed storage, big data analysis, software-defined storage, video, backup and archiving, and other storage-intensive cold storage scenarios. It delivers unmatched flexibility and expandability of local storage, reduced storage costs, as well as high computing performance.

The 2298 V5 features ultra-high density, superb performance, easy O&M, and high expandability.

Figure 1-1 2298 V5



2 Features

Performance and Scalability

- Powered by two Intel® Xeon® Scalable Skylake or Cascade Lake processors, the server provides up to 28 cores, 3.8 GHz frequency, a 38.5 MB L3 cache, and two 10.4 GT/s UPI links between the processors, which deliver supreme processing performance.
 - It supports up to two processors with 56 cores and 112 threads to maximize the concurrent execution of multithreaded applications.
 - An L2 cache is added. Each core can exclusively use 1 MB of L2 cache and at least 1.375 MB of L3 cache.
 - Intel Turbo Boost Technology 2.0 allows processor cores to run faster than the frequency specified in the Thermal Design Power (TDP) configuration if they are operating below power, current, and temperature specification limits.
 - Intel Hyper-Threading Technology enables each processor core to run up to two threads, improving parallel computation capability.
 - The hardware-assisted Intel® Virtualization Technology (Intel® VT) allows operating system (OS) vendors to better use hardware to address virtualization workloads.
 - Intel® Advanced Vector Extensions 512 (Intel AVX-512) significantly accelerates floating-point performance for computing-intensive applications.
 - The Cascade Lake processors support Intel® Deep Learning Boost vector neural network instructions (VNNI) to improve the performance of deep learning applications.
- The server supports double data rate 4 (DDR4) registered dual in-line memory modules (RDIMMs) and load-reduced DIMMs (LRDIMMs) with error checking and correcting (ECC). A server fully configured with twelve 2933 MT/s memory modules (only available with Cascade Lake processors) provides 768 GB memory space and the maximum theoretical memory bandwidth of 274.96875 GB/s.
- Flexible drive configurations cater to a variety of business requirements and ensure high elasticity and scalability of storage resources.
- SATA/SAS SSDs or NVMe drives can be used as the cache to improve drive performance.

- The LANs on motherboard (LOMs) and Open Compute Project (OCP) 2.0 mezzanine cards provide a variety of ports to meet different networking requirements.
- The server supports up to four PCIe 3.0 slots.
- With Intel integrated I/O, the Intel® Xeon® Scalable processors integrate the PCIe 3.0 controller to shorten I/O latency and improve overall system performance.

Availability and Serviceability

- Carrier-class components with process expertise ensure high system reliability and availability.
- The server supports twenty-four 3.5-inch front SAS/SATA drives and four 2.5-inch rear SAS/SATA/NVMe drives. All the drives are hot-swappable, and the 2.5-inch SAS/SATA drives support RAID1, 10, and 1E.
- The SSDs offer better reliability than HDDs, ensuring continued system performance.
- The server provides simplified O&M and efficient troubleshooting through the UID/HLY indicators on the front panel and iBMC web interface.
- The built-in iBMC monitors system parameters in real time, triggers alarms, and performs recovery actions to minimize the system downtime.
- Huawei provides a three-year warranty for parts replacement and onsite repair for the servers used in China. Huawei provides a 10-hour-a-day, 7-day-a-week support program. Service requests will be handled the next business day. Optional service upgrades are available.
- Huawei provides a three-year warranty for parts replacement and repair for the servers used outside China. Huawei provides a 9-hour-a-day, 5-day-a-week support program. Service requests will be handled the next business day. Huawei delivers the repaired or new parts within 45 calendar days after receiving the defective parts.

Manageability and Security

- The built-in iBMC monitors server operating status and provides remote management.
- A password is required for accessing the BIOS, ensuring system boot and management security.
- The Network Controller Sideband Interface (NC-SI) allows a network port to serve as a management port and a service port for maximized return on investment (ROI) for customers. The NC-SI feature is disabled by default and can be enabled through the iBMC or BIOS.
- The integrated Unified Extensible Firmware Interface (UEFI) improves setup, configuration, and update efficiency and simplifies fault handling.
- The Advanced Encryption Standard–New Instruction (AES NI) algorithm allows faster and stronger encryption.
- Intel Execute Disable Bit (EDB) function prevents certain types of malicious buffer overflow attacks when working with a supported OS.
- Intel Trusted Execution Technology enhances security using hardware-based defense against malicious software attacks, allowing applications to run independently.

- The trusted platform module (TPM) and trusted cryptography module (TCM) provide advanced encryption functions, such as digital signatures and remote authentication.

 **NOTE**

The service port with NC-SI enabled supports the following configuration:


- Configuring any port on the LOM, OCP 2.0 mezzanine card 1, or PCIe NIC as the service port with NC-SI enabled. Host port 1 is configured by default.
- Enabling, disabling, and setting a virtual local area network (VLAN) ID for this port. The VLAN ID is 0 and disabled by default.
- Configuring IPv4 addresses (IPv4 address, subnet mask, and gateway) and IPv6 addresses (IPv6 address, prefix length, and gateway) for this port.

Energy Efficiency

- The 80 Plus Platinum power supply units (PSUs) of multiple power ratings provide 94% power efficiency at 50% load.
- The server supports active/standby power supplies and high-voltage DC (HVDC) for improved power supply efficiency.
- Efficient voltage regulator-down (VRD) power supplies for boards minimize the energy loss from DC/DC power conversion.
- Area-based, Proportional-Integral-Derivative (PID) intelligent fan speed adjustment and intelligent CPU frequency scaling optimize heat dissipation and reduce overall system power consumption.
- The improved thermal design with energy-efficient fans ensures optimal heat dissipation and reduces system power consumption.
- The server is protected with power capping and power control measures.
- Staggered spin-up for drives reduces the server boot power consumption.
- Intel® Intelligent Power Capability allows a processor to be powered on or off based on requirements.
- Low-voltage Intel® Xeon® Scalable processors consume less energy, ideally suited for data centers and telecommunications environments constrained by power and thermal limitations.
- SSDs consume 80% less power than HDDs.

3 Physical Structure


Figure 3-1 2298 V5 physical structure



1	Rear drives	2	Rear drive module
3	PCIe riser module	4	Standard PCIe cards
5	PSUs	6	Chassis
7	Air duct 1	8	Upper drive drawer
9	Lower drive drawer	10	Fan module bracket
11	Fan modules	12	Air duct 2
13	Heat sinks	14	Processors
15	Memory modules	16	TPM/TCM
17	Mainboard	18	OCP 2.0 mezzanine card

4 Logical Structure

Figure 4-1 2298 V5 logical structure



- The server supports one or two Intel® Xeon® Scalable processors.
- The server supports up to 12 memory modules.
- The CPUs (processors) interconnect with each other through two UPI links at a speed of up to 10.4 GT/s.
- The CPUs are directly connected to five PCIe slots:
 - CPU 1 is connected to two full-height half-length (FHHL) PCIe 3.0 x8 cards and one PCIe 3.0 x8 OCP 2.0 mezzanine card.
 - CPU 2 is connected to two half-height half-length (HHHL) PCIe 3.0 x16 cards.
- The server supports 24 front 3.5-inch SAS/SATA drives directly connected to a 24-port PCIe SAS HBA card.
- The server supports four rear 2.5-inch SAS/SATA/NVMe drives that can be directly connected to the following signal sources:
 - PCIe RAID controller card when SAS/SATA drives are configured
 - PCH SATA interface when SATA drives are configured

- CPU PCIe interface when NVMe drives are configured
- The LBG-2 Platform Controller Hub (PCH) supports:
 - Two 10GE optical LOM ports
 - Two GE electrical LOM ports
 - Two SATA or PCIe ports for M.2 SSDs
- The server uses Hi1710 management chip and supports a video graphic array (VGA) port, a management network port, and a debug serial port.


5 Hardware Description

- 5.1 Front Panel
- 5.2 Rear Panel
- 5.3 Processor
- 5.4 Memory
- 5.5 Storage
- 5.6 Network
- 5.7 I/O Expansion
- 5.8 PSUs
- 5.9 Fans
- 5.10 Boards

5.1 Front Panel

5.1.1 Appearance

Figure 5-1 Front view




1	Drive drawer ejector lever	2	Release slider of the drive drawer ejector lever
3	Upper drive drawer	4	Mounting ear ejector lever
5	Lower drive drawer	6	Slide-out label plate (with an SN label)

5.1.2 Indicators and Buttons

Positions



Figure 5-2 Indicators and buttons on the front panel






1	Power button/indicator	2	Health status indicator
3	10GE optical port (LOM port 1) connection status indicator	4	GE electrical port (LOM port 3) connection status indicator
5	UID button/indicator	6	NMI button
7	10GE optical port (LOM port 2) connection status indicator	8	GE electrical port (LOM port 4) connection status indicator
9	Status indicators of the drives in the front drawers	-	-

Indicator and Button Description

Table 5-1 Indicators and buttons on the front panel

Silkscreen	Indicator/ Button	Description
	Power button/ indicator	<p>Power indicator:</p> <ul style="list-style-type: none"> ● Off: The device is not powered on. ● Steady green: The device is powered on. ● Blinking yellow: The power button is locked. The power button is locked when the iBMC is starting. ● Steady yellow: The device is ready to power on. <p>Power button:</p> <ul style="list-style-type: none"> ● When the device is powered on, you can press this button to gracefully shut down the OS. ● When the device is powered on, holding down this button for 6 seconds will forcibly power off the device. ● When the power indicator is steady green, you can press this button to power on the device.
	UID button/ indicator	<p>The UID button/indicator helps identify and locate a device.</p> <p>UID indicator:</p> <ul style="list-style-type: none"> ● Off: The device is not being located. ● Blinking blue: The device has been located and is distinguished from other devices that have also been located. ● Steady blue: The device is being located. <p>UID button:</p> <ul style="list-style-type: none"> ● You can turn on or off the UID indicator by pressing the UID button on the panel or by using the iBMC CLI or WebUI. ● You can press this button to turn on or off the UID indicator. ● You can press and hold down this button for 4 to 6 seconds to reset the iBMC.

Silkscreen	Indicator/ Button	Description
	Health status indicator	<ul style="list-style-type: none"> • Off: The device is powered off or is faulty. • Blinking red at 1 Hz: A major alarm has been generated on the system. • Blinking red at 5 Hz: A critical alarm has been generated on the system. • Steady green: The device is operating properly.
○	NMI button	<p>A non-maskable interrupt (NMI) is generally triggered to stop the OS for debugging. To trigger an NMI, press this button or click the button on the iBMC WebUI.</p> <p>NOTICE</p> <ul style="list-style-type: none"> • Press the NMI button only when the OS is abnormal. Do not press this button when the server is operating properly. An NMI does not gracefully shut down the OS and causes service interruption and data loss. • Before pressing the NMI button, ensure that the OS has the NMI processing program. Otherwise, the OS may crash. Exercise caution when pressing this button.
	LOM port connection status indicator	<p>Each indicator shows the connection status of an Ethernet LOM port.</p> <ul style="list-style-type: none"> • Off: The network port is not in use or has failed. • Steady green: The network port is properly connected. <p>NOTE</p> <ul style="list-style-type: none"> • The indicators correspond to two 10GE and two GE network ports on the mainboard. • The LOM has a standby power supply and will not be powered off even if the service system is powered off. As long as the peer network devices are operating, the network ports will remain connected and the indicators are on.
	Status indicators of the drives in the front drawers	<p>Indicate the status of the drives in the front drive drawers.</p> <p>For details, see Front Drive Drawer Indicators (3.5-inch SAS/SATA drives).</p>

5.1.3 Ports

Port Positions

Figure 5-3 Ports on the front panel



1	USB 3.0 ports	2	VGA port
---	---------------	---	----------

Port Description


Table 5-2 Ports on the front panel

Port	Type	Quantity	Description
USB port	USB 3.0	2	Used to connect to a USB device. NOTICE Before connecting an external USB device, check that the USB device functions properly. The server may operate abnormally if an abnormal USB device is connected.
VGA port	DB15	1	Used to connect a display terminal, such as a monitor or KVM.

5.2 Rear Panel

5.2.1 Appearance

Figure 5-4 Rear view



1	SAS/SATA/NVMe drives	2	Rear drive module
3	PCIe Slot1	4	PCIe Slot2
5	PCIe riser module	6	PCIe Slot4
7	PCIe Slot3	8	PSU 1
9	PSU 2	10	LOM
11	(Optional) OCP 2.0 mezzanine card	-	-


NOTE

- For details about the LOM and OCP 2.0 mezzanine card, see [Network](#).
- The preceding figure is for reference only.

5.2.2 Indicators

Indicator Positions

Figure 5-5 Indicators on the rear panel



1	PSU indicator	2	UID indicator
3	Serial port indicators NOTE The indicators are reserved.	4	Connection status indicator for the management network port
5	Data transmission status indicator of the management network port	6	LOM indicators
7	OCP 2.0 mezzanine card indicators	-	-

Indicator Description

Table 5-3 Indicators on the rear panel


Indicator	Description
PSU indicator	<ul style="list-style-type: none"> ● Off: No power is supplied. ● Blinking green at 1 Hz: <ul style="list-style-type: none"> - The input is normal, and the server is standby. - The input is overvoltage or undervoltage. - The PSU is in deep hibernation mode. ● Blinking green at 4 Hz: The firmware is being upgraded online. ● Steady green: The power input and output are normal. ● Steady orange: The input is normal, but no power output is supplied. <p>NOTE The possible causes of no power output are as follows:</p> <ul style="list-style-type: none"> ● Power supply overtemperature protection ● Power output overcurrent or short-circuit ● Output overvoltage ● Short-circuit protection ● Device failure (excluding failure of all devices)

Indicator	Description
UID indicator	The UID indicator helps identify and locate a device. <ul style="list-style-type: none"> Off: The device is not being located. Blinking blue: The device has been located and is differentiated from other devices that have also been located. Steady blue: The device is being located. NOTE You can turn on or off the UID indicator by pressing the UID button or remotely running a command on the iBMC CLI.
Connection status indicator for the management network port	<ul style="list-style-type: none"> Off: The network port is not connected. Steady green: The network network port is properly connected.
Data transmission status indicator for the management network port	<ul style="list-style-type: none"> Off: No data is being transmitted. Blinking yellow: Data is being transmitted.
LOM indicators	For details, see LOMs .
OCP 2.0 mezzanine card indicators	For details, see OCP 2.0 Mezzanine Cards .

5.2.3 Ports

Port Positions

Figure 5-6 Ports on the rear panel



1	Socket for PSU 1	2	Socket for PSU 2
3	Serial port	4	Management network port

5	LOM ports (GE)	6	VGA port
7	LOM ports (10GE)	8	USB 3.0 ports
9	Reserved ports	10	OCP 2.0 mezzanine card ports

Port Description

Table 5-4 Ports on the rear panel

Port	Type	Quantity	Description
PSU socket	-	2	Used to connect to the power distribution unit (PDU) in the cabinet. You can select the number of power supply units (PSUs) as required. NOTE <ul style="list-style-type: none"> When determining the quantity of PSUs, ensure that the rated power of the PSUs is greater than that of the server. If only one PSU is used, Predicted PSU Status cannot be set to Active/Standby on the iBMC WebUI.
Serial port	RJ45	1	Default system serial port used for debugging. You can also set the iBMC serial port as the system debug port by using the iBMC command. NOTE The port uses 3-wire serial communication interface, and the default baud rate is 115,200 bit/s.
Management network port	1000BASE-T	1	Used for server management. NOTE The management network port is a GE port that supports 100 Mbit/s and 1000 Mbit/s auto-negotiation.
LOM port	10GE optical port	2	For details, see LOMs .
	GE electrical port	2	

Port	Type	Quantity	Description
VGA port	DB15	1	Used to connect a display terminal, such as a monitor or KVM.
USB 3.0 port	USB 3.0	2	Used to connect to a USB device. NOTICE Before connecting an external USB device, check that the USB device functions properly. The server may operate abnormally if an abnormal USB device is connected.
OCP 2.0 mezzanine card port	-	-	For details, see OCP 2.0 Mezzanine Cards .


5.3 Processor

- The server supports one or two processors.
- If only one processor is required, install it in socket **CPU1**.
- The same model of processors must be used in a server.
- Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.

NOTICE

According to Intel's statement, the processors in overlocking mode may cause instantaneous thermal throttling on certain OSs. The thermal throttling, however, does not affect the processor performance and reliability.

Figure 5-7 Processor positions




5.4 Memory

5.4.1 Memory Identifier

You can determine the memory module properties based on the label attached to the memory module.

Figure 5-8 Memory identifier



callout	Description	Definition
1	Capacity of the memory module	<ul style="list-style-type: none"> • 8 GB • 16 GB • 32 GB • 64 GB • 128 GB
2	Number of ranks of the memory module	<ul style="list-style-type: none"> • 1R: single-rank • 2R: dual-rank • 4R: quad-rank • 8R: octal-rank
3	Data width on the DRAM	<ul style="list-style-type: none"> • X4: 4-bit • X8: 8-bit
4	Type of the memory interface	<ul style="list-style-type: none"> • PC3: DDR3 • PC4: DDR4
5	Maximum memory speed	<ul style="list-style-type: none"> • 2133 MT/S • 2400 MT/S • 2666 MT/S • 2933 MT/S
6	Column Access Strobe (CAS) latency	<ul style="list-style-type: none"> • P: 15 • T: 17
7	DIMM type	<ul style="list-style-type: none"> • R: RDIMM • L: LRDIMM

5.4.2 Memory Subsystem Architecture

The 2298 V5 provides 12 memory slots. Each processor integrates six memory channels.

Table 5-5 Memory channels

CPU	Memory Channel	Memory Slot
CPU 1	A	DIMM000(A)
	B	DIMM010(B)
	C	DIMM020(C)
	D	DIMM030(D)
	E	DIMM040(E)

CPU	Memory Channel	Memory Slot
	F	DIMM050(F)
CPU 2	G	DIMM100(G)
	H	DIMM110(H)
	I	DIMM120(I)
	J	DIMM130(J)
	K	DIMM140(K)
	L	DIMM150(L)

5.4.3 Memory Compatibility

Observe the following rules when configuring DDR4 memory modules:

NOTICE

- A server must use the same model of DDR4 memory modules, and all the memory modules operate at the same speed, which is the smallest value of:
 - Memory speed supported by a processor
 - Maximum operating speed of a memory module
 - The DDR4 memory modules of different types (RDIMM and LRDIMM) and specifications (capacity, bit width, rank, and height) cannot be used together.
 - Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.
-
- The memory can be used with Intel® Xeon® Scalable Skylake and Cascade Lake processors. The maximum memory capacity supported varies depending on the processor model.
 - Skylake processors
 - M processors: 1.5 TB/socket
 - Other processors: 768 GB/socket
 - Cascade Lake processors
 - L processors: 4.5 TB/socket
 - M processors: 2 TB/socket
 - Other processors: 1 TB/socket
 - The total memory capacity is the sum of the capacity of all DDR4 memory modules.

NOTICE

The total memory capacity cannot exceed the maximum memory capacity supported by the CPUs.

- Use the **Intelligent Computing Compatibility Checker** to determine the capacity type of a single memory module.
- The maximum number of memory modules supported by a server varies depending on the CPU type, memory type, rank quantity, and operating voltage.

 **NOTE**

Each memory channel supports a maximum of 8 ranks. The number of memory modules supported by each channel varies depending on the number of ranks supported by each channel:

Number of memory modules supported by each channel ≤ Number of ranks supported by each memory channel/Number of ranks supported by each memory module

Table 5-6 DDR4 memory specifications

Parameter		Specifications				
Maximum capacity per DDR4 memory module (GB)		16	16	32	32	64
Rated speed (MT/s)		2666	2933	2666	2933	2933
Rank		Dual rank	Dual rank	Dual rank	Dual rank	Dual rank
Operating voltage (V)		1.2	1.2	1.2	1.2	1.2
Maximum number of DDR4 memory modules in a server ^a		12	12	12	12	12
Maximum DDR4 memory capacity of the server (GB) ^b		192	192	384	384	768
Maximum operating speed (MT/s)	1DPC ^c	2666	2933 ^d	2666	2933 ^d	2933 ^d

Parameter	Specifications
	<ul style="list-style-type: none"> • a: The maximum number of DDR4 memory modules is based on dual-processor configuration. The value is halved for a server with only one processor. • b: The maximum DDR4 memory capacity varies depending on the processor type. The value listed in this table is based on the assumption that memory modules are fully configured. • c: DPC (DIMM per channel) indicates the number of DIMMs per channel. • d: If the Cascade Lake processor is used, the maximum operating speed of a memory module can reach 2933 MT/s. If the Skylake processor is used, the maximum operating speed of a memory module can reach 2666 MT/s only.

5.4.4 Memory Installation Guidelines

- Observe the following when configuring DDR4 memory modules:
 - Install memory modules only when corresponding processors are installed.
 - Do not install LRDIMMs and RDIMMs in the same server.
 - Install filler memory modules in vacant slots.
- Observe the following when configuring DDR4 memory modules in specific operating mode:
 - Memory sparing mode
 - Comply with the general installation guidelines.
 - Each memory channel must have a valid online spare configuration.
 - The channels can have different online spare configurations.
 - Each populated channel must have a spare rank.
 - Memory mirroring mode
 - Comply with the general installation guidelines.
 - Install memory modules for channels 1 and 2 or channels 3 and 4. The memory modules installed must be identical in size and organization.
 - For a multi-processor configuration, each processor must have a valid memory mirroring configuration.
 - Memory scrubbing mode
 - Comply with the general installation guidelines.

5.4.5 Memory Installation Positions

A 2298 V5 supports a maximum of 12 DDR4 memory modules. Balanced memory configuration is recommended for optimal memory performance.

NOTICE

At least one DDR4 memory module must be installed in the memory slots corresponding to CPU 1.

Figure 5-9 Memory slots




Figure 5-10 DDR4 memory installation guidelines (1 processor)

CPU	Channel	DIMM Slot	Number of DIMMs (✓: recommended ○: not recommended)					
			✓	✓	✓	✓	○	✓
			1	2	3	4	5	6
CPU1	A	DIMM000(A)	•	•	•	•	•	•
	B	DIMM010(B)		•	•	•	•	•
	C	DIMM020(C)			•		•	•
	D	DIMM030(D)				•	•	•
	E	DIMM040(E)				•	•	•
	F	DIMM050(F)						•

Figure 5-11 DDR4 memory installation guidelines (2 processors)

CPU	Channel	DIMM Slot	Number of DIMMs												
			(✓: recommended ○: not recommended)												
			○	✓	○	✓	○	✓	○	✓	○	○	○	✓	
			1	2	3	4	5	6	7	8	9	10	11	12	
CPU1	A	DIMM00(A)	•	•	•	•	•	•	•	•	•	•	•	•	
	B	DIMM01(B)			•	•	•	•	•	•	•	•	•	•	
	C	DIMM02(C)					•	•			•	•	•	•	
	D	DIMM03(D)							•	•	•	•	•	•	
	E	DIMM04(E)								•	•	•	•	•	
	F	DIMM05(F)												•	•
CPU2	G	DIMM10(G)		•	•	•	•	•	•	•	•	•	•	•	
	H	DIMM11(H)				•	•	•	•	•	•	•	•	•	
	I	DIMM12(I)						•	•	•	•	•	•	•	
	J	DIMM13(J)								•	•	•	•	•	
	K	DIMM14(K)											•	•	•
	L	DIMM15(L)													•

5.4.6 Memory Protection Technologies

The following memory protection technologies are supported:

- ECC
- Full mirroring
- Address range mirroring
- Rank sparing mode
- Faulty DIMM isolation
- Memory thermal throttling
- Memory address parity protection
- Adaptive double device data correction (ADDDC)
- Memory demand/patrol scrubbing
- Data Scrambling
- ADDDC+1

5.5 Storage

5.5.1 Drive Configurations

Table 5-7 Drive configurations


Configuration	Maximum Drives	Drive Management Mode
Front drives	24 <ul style="list-style-type: none"> • Slots 0 to 23 support only 3.5-inch SAS/SATA drives. 	SAS HBA card ^a

Configuration	Maximum Drives	Drive Management Mode
Rear drives	4 <ul style="list-style-type: none"> • Slots R0 to R3 support 2.5-inch SAS/SATA/NVMe drives. 	RAID controller card ^b /PCH ^c /CPU ^d
Built-in drives	2 <ul style="list-style-type: none"> • Supports two built-in M.2 SSDs.^e 	PCH
<ul style="list-style-type: none"> • a: The front drives are configured with 24-port SAS HBA cards. • b: If SATA/SAS drives are used as rear drives, a PCIe RAID controller card can be configured to manage the rear drives. • c: The SATA drives used as rear drives can be directly connected to the PCH. • d: The NVMe drives used as rear drives can be directly connected to the CPU. • e: The M.2 SSDs come in two sizes 2242 and 2280, and supports SATA and PCIe interfaces. • Contact your local Huawei sales representative or use the Intelligent Computing Compatibility Checker to determine the components to be used. 		

5.5.2 Drive Numbering


- Front drives

Figure 5-12 Drive numbering




- Rear drives

Figure 5-13 Drive numbering



- Built-in drives (M.2 SSD-0/1)

Figure 5-14 Drive numbering



5.5.3 Drive Indicators

Front Drive Drawer Indicators (3.5-inch SAS/SATA drives)

Figure 5-15 Indicators of the front drive drawer




Table 5-8 Description of identification indicators of the front drive drawer

Drive Identification Indicator (Blue)	Description
Steady on	The drive is being located.
Off	The drive is not in position.

Table 5-9 Description of status indicators of the front drive drawer

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Blinking at 0.5 Hz	Off	The RAID group is being rebuilt or the member drive is being replaced.
Blinking at 1 Hz	Off	The drive is being identified or to be deleted.

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Blinking	Off	The drive is being accessed. NOTE The blinking speed indicates the number of I/Os.
Steady on	Off	The drive is online.
Off	Blinking at 8 Hz	The drive is faulty.
Blinking (on for 0.5s and off for 1s)	Blinking (on for 0.5s and off for 1s)	The drive is in prefail state.
Blinking (on for 3s and off for 3s)	Blinking (on for 3s and off for 3s)	The RAID group rebuilding is suspended.
Off	Off	The drive is not in position.

SAS/SATA Drive Indicators

Figure 5-16 SAS/SATA drive indicators





Table 5-10 Description of SAS/SATA drive indicators

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Steady on	Off	The drive is in position.
Blinking at 4 Hz	Off	Data is being read or written normally, or data on the primary drive is being rebuilt.
Steady on	Blinking at 1 Hz	The drive is being located.
Blinking at 1 Hz	Blinking at 1 Hz	The data on the secondary drive is being rebuilt.
Off	Steady on	A member drive in the RAID array is removed.

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Steady on	Steady on	The drive is faulty.

NVMe Drive Indicators

Figure 5-17 NVMe drive indicators



- If the VMD function is enabled and the latest VMD driver is installed, the NVMe drives support surprise hot swap.

Table 5-11 Description of NVMe drive indicators (VMD enabled)

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Off	Off	The NVMe drive cannot be detected.
Steady on	Off	The NVMe drive is working properly.
Blinking at 2 Hz	Off	Data is being read from or written to the NVMe SSD.
Off	Blinking at 2 Hz	The NVMe drive is being located.
Off	Blinking at 8 Hz	The data on the secondary NVMe drive is being rebuilt.
Steady on/Off	Steady on	The NVMe drive is faulty.

- If the VMD function is disabled, NVMe drives support only orderly hot swap.

Table 5-12 NVMe drive indicators (VMD disabled)

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Off	Off	The NVMe drive cannot be detected.

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Steady on	Off	The NVMe drive is working properly.
Blinking at 2 Hz	Off	Data is being read from or written to the NVMe drive.
Off	Blinking at 2 Hz	The NVMe drive is being located or hot-swapped.
Off	Blinking at 0.5 Hz	The hot removal process is complete, and the NVMe drive is removable.
Steady on/Off	Steady on	The NVMe drive is faulty.

5.5.4 RAID Controller Card

The RAID controller card supports RAID configuration, RAID level migration, and drive roaming.

- If SAS/SATA drives are used as rear drives, a RAID controller card can be configured to manage the rear drives.
- Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.

Table 5-13 RAID levels supported by the 2298 V5

RAID Level	Reliability	Read Performance	Write Performance	Minimum Number of Drives	Drive Utilization
RAID 1	High	High	Low	2	50%
RAID 10	High	High	Medium	4	50%
RAID 1E	High	Medium	Medium	3	50%

5.6 Network

5.6.1 LOMs


LOMs provide network expansion capabilities.

Table 5-14 LOMs supported by the 2298 V5

NIC Type	Chip Model	Port Type	Number of Ports	NC-SI	WOL	PXE
LOM	X722	10GE optical port	2	√	√	√
		GE electrical port	2	√	√	√

- Use **Intelligent Computing Compatibility Checker** to obtain information about the cables and optical modules supported by the LOM ports.
- Rate specifications of the LOM ports (10GE optical ports):
 - Rate negotiation mode: auto-negotiation 10000 Mbit/s (full duplex)
 - Supported rate: 10000 Mbit/s
 - Rates not supported: 10/100/1000 Mbit/s
- Rate specifications of the LOM ports (GE electrical ports):
 - Rate negotiation mode: auto-negotiation 1000 Mbit/s (full duplex)
 - Supported rate: 1000 Mbit/s
 - Rates not supported: 10/100 Mbit/s
- The LOM ports do not support forced rates.
- The electrical LOM ports cannot be connected to power over Ethernet (PoE) devices (such as a switch with PoE enabled). Connecting a LOM port to a PoE device may cause link communication failure or even damage the NIC.
- The electrical LOM ports do not support SR-IOV.
- Forcibly powering off a server will cause intermittent NC-SI disconnection and disable the Wake on LAN (WOL) function of the LOM ports. To restore the NC-SI connection, refresh the iBMC WebUI.


Figure 5-18 LOM ports



1	10GE optical port (LOM port 1)	2	10GE optical port (LOM port 2)
3	GE electrical port (LOM port 3)	4	GE electrical port (LOM port 4)

Indicator Positions

Figure 5-19 LOM indicators



1	Connection status indicator/Data transmission status indicator for a 10GE optical port	2	Data transmission rate indicator for a 10GE optical port
3	Data transmission status indicator for a GE electrical port	4	Connection status indicator for a GE electrical port

Indicator Description

Table 5-15 LOM indicators

Indicator	Description
Connection status indicator/Data transmission status indicator for a 10GE optical port	<ul style="list-style-type: none"> Off: The network port is not connected. Blinking green: Data is being transmitted. Steady green: The network port is properly connected.
Data transmission rate indicator for a 10GE optical port	<ul style="list-style-type: none"> Off: The network port is not connected. Steady green: The data transmission rate is 10 Gbit/s. Steady yellow: The data transmission rate is lower than 10 Gbit/s.
Data transmission status indicator for a GE electrical port	<ul style="list-style-type: none"> Off: The network port is not connected. Steady yellow: The network port is in active status. Blinking yellow: Data is being transmitted.

Indicator	Description
Connection status indicator for a GE electrical port	<ul style="list-style-type: none"> Off: The network port is not connected. Steady green: The network port is properly connected.

5.6.2 OCP 2.0 Mezzanine Cards

OCP 2.0 mezzanine cards provide network expansion capabilities.

- Supports on-demand configuration.
- Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.


Table 5-16 OCP 2.0 mezzanine card supported by the 2298 V5

NIC Type	Chip Model	Port Type	Number of Ports	NC-SI	WOL	PXE
OCP 2.0 mezzanine card	CX5	25GE optical port	2	√	√	√

Indicator Positions

- OCP 2.0 mezzanine card indicators (2 x 25GE optical ports)

Figure 5-20 OCP 2.0 mezzanine card indicators (2 x 25GE optical ports)



1	Connection status indicator/Data transmission status indicator for a 25GE optical port	2	Data transmission rate indicator for a 25GE optical port
---	--	---	--

Indicator Description

Table 5-17 OCP 2.0 mezzanine card indicators

Indicator	Description
Connection status indicator/Data transmission status indicator for a 25GE optical port	<ul style="list-style-type: none"> Off: The network port is not connected. Blinking green: Data is being transmitted. Steady green: The network port is properly connected.
Data transmission rate indicator for a 25GE optical port	<ul style="list-style-type: none"> Off: The network port is not connected. Steady green: The data transmission rate is 25 Gbit/s. Steady yellow: The data transmission rate is 10 Gbit/s.

5.7 I/O Expansion

5.7.1 PCIe Cards


PCIe cards provide ease of expandability and connection.

- Four slots for standard PCIe cards are supported.
- Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.

5.7.2 PCIe Slots

PCIe Slots


Figure 5-21 PCIe slots



- Slots 1 and 2 are provided by the PCIe riser module. By default, slot 1 is configured with a 24-port SAS HBA card.
- Slots 3 and 4 are provided by the mainboard.

PCIe Riser Module

Figure 5-22 PCIe riser module



5.7.3 PCIe Slot Description

NOTE

The PCIe slots mapping to a vacant CPU socket are unavailable.

Table 5-18 PCIe slot description

PCIe Slot	CPU	PCIe Standards	Connector Width	Bus Width	Port No.	Root Port (B/D/F)	Device (B/D/F)	Slot Size
LOM	CPU1	PCIe 3.0	x8	x8	Port1C	85/02/0	89/00/0	-

PCIe Slot	CPU	PCIe Standards	Connector Width	Bus Width	Port No.	Root Port (B/D/F)	Device (B/D/F)	Slot Size
OCP 2.0 mezzanine card	CPU 1	PCIe 3.0	x8	x8	Port1A	17/00/0	18/00/0	-
Slot 1	CPU 1	PCIe 3.0	x16	x8	Port3A	5D/00/0	5E/00/0	FHHL
Slot 2	CPU 1	PCIe 3.0	x16	x8	Port3C	5D/02/0	5F/00/0	FHHL
Slot 3	CPU 2	PCIe 3.0	x16	x16	Port2A	85/00/0	85/00/0	HHHL
Slot 4	CPU 2	PCIe 3.0	x16	x16	Port3A	AE/00/0	AE/00/0	HHHL

- The B/D/F (Bus/Device/Function Number) values are the default values when the server is fully configured with PCIe devices. The values may vary if the server is not fully configured with PCIe devices or if a PCIe card with a PCI bridge is configured.
- Root Port (B/D/F) indicates the B/D/F of an internal PCIe root port of the processor.
- Device (B/D/F) indicates the B/D/F (displayed on the OS) of an onboard or extended PCIe device.
- The PCIe x16 slots are backward compatible with PCIe x8, PCIe x4, and PCIe x1 cards. The PCIe cards are not forward compatible. That is, the PCIe slot width cannot be smaller than the PCIe card link width.
- The full-height half-length (FHHL) PCIe slots are backward compatible with half-height half-length (HHHL) PCIe cards.
- All slots support PCIe cards of up to 75 W. The power of a PCIe card varies depending on its model.
- The SP520, SP521, and SP522 do not support driveless server configuration. PXE boot is recommended for driveless servers.

5.8 PSUs

- The server supports one or two PSUs.
- The server supports AC or DC PSUs.
- The PSUs are hot-swappable.
- The server supports two PSUs in 1+1 redundancy.
- The same model of PSUs must be used in a server.


- The PSUs are protected against short circuit. Double-pole fuse is provided for the PSUs with dual input live wires.
- Contact your local Huawei sales representative or use the [Intelligent Computing Compatibility Checker](#) to determine the components to be used.

NOTE

For a server configured with one or two 1500 W Platinum AC PSUs:

- When the input voltage is from 100 V AC to 132 V AC, the output power drops to 1000 W.
- Two 1500 W AC Platinum PSUs can serve as 1700 W PSUs.


Figure 5-23 PSU positions



5.9 Fans

- The server supports five fan modules.
- The fan modules are hot-swappable.
- The server tolerates failure of a single fan.
- The fan speed can be adjusted.
- The same model of fan modules must be used in a server.


Figure 5-24 Fan module positions



5.10 Boards

5.10.1 Mainboard

Figure 5-25 2298 V5 mainboard




1	UID button/indicator (S1)	2	Management network port + management serial port (J13)
3	LOM GE port (J11)	4	TPM/TCM port (TPM CONN/J55)
5	VGA connector (VGA CONN/J112)	6	PCIe riser slots (PCIE RISER/J1/J8/J9)
7	10GE optical port (J132)	8	10GE optical port (J131)
9	mini-SAS HD connector (MINIHD PORTA/J86)	10	USB 3.0 port (USB3.0 CONN/J169)
11	I ² C management network port (I2C/J10) ^a	12	USB 3.0 port (INNER USB3.0/J173)
13	OCP 2.0 mezzanine card slot (OCP CARD/J5)	14	Right mounting ear connector (REAR BOARD/J186)

15	CPU 1 slimline connector (CPU0 PORTA/J181)	16	CPU 1 slimline connector (CPU0 PORTB/J170)
17	Rear-drive backplane power connector (PWR OUT/J172)	18	Rear-drive backplane management connector (REAR HDD BP/J164)
19	Fan 5 port (FAN4/J143)	20	Fan 4 port (FAN3/J102)
21	Fan 3 port (FAN2/J103)	22	Upper drive drawer management cable connector (HDD BP CONN0/J7)
23	Fan 2 port (FAN1/J104)	24	Left mounting ear connector (LEAR BOARD/J167)
25	Fan 1 port (FAN0/J105)	26	Lower drive drawer management cable connector (HDD BP CONN1/J162)
27	Mainboard power connector (PWR IN1/J185)	28	Mainboard power connector (PWR IN0/J184)
29	PSU management connector (J182)	30	RTC battery (CMOS BATTY/U4042)
31	Onboard PCIe slot (J179)	32	Onboard PCIe slot (J180)
33	PCIe standard card NC-SI port (NCSI CONN/J99)	34	VROC key port (SOFT RAID KEY/J130) ^a
<ul style="list-style-type: none"> • a: This port is a reserved port, which is unavailable. 			

5.10.2 Drive Backplane

Front Drawer Drive Backplane


Figure 5-26 Front drawer drive backplane (BOM 03025YVL)



1	Drive connector (J20)	2	Backplane management signal cable connector (J1)
3	Slimline connector (PORT A)	4	Drive identification indicator
5	Indicator signal cable connector (J1701)	6	Slimline connector (PORT B)
7	Power connector (J2)	-	-

Rear-Drive Backplane

Figure 5-27 Rear-drive backplane (BOM 03024BPV)



1	Power connector (REAR BP POWR3/J22)	2	mini-SAS HD connector (Port A/J2)
3	Slimline A connector (SLIMLINE A/J8)	4	Slimline B connector (SLIMLINE B/J9)
5	Backplane signal cable connector (HDD BP/J23)	-	-

6 Product Specifications

[6.1 Technical Specifications](#)

[6.2 Environmental Specifications](#)

[6.3 Physical Specifications](#)

6.1 Technical Specifications

Table 6-1 Technical specifications

Category	Specifications
Form factor	2U rack server
Chipset	Intel® C622
Processors	<p>Supports one or two processors.</p> <ul style="list-style-type: none">• Intel® Xeon® Scalable (Skylake and Cascade Lake) processors• Built-in memory controller and six memory channels• Built-in PCIe controller, supporting PCIe 3.0 and 48 lanes per processor• Two UPI buses between processors, providing up to 10.4GT/s transmission per channel• Up to 28 cores (2.7 GHz)• Max. 3.8 GHz (four cores)• Min. 1.375 MB L3 cache per core• Max. 205 W TDP <p>NOTE The preceding information is for reference only. Use the Intelligent Computing Compatibility Checker to obtain specific information.</p>

Category	Specifications
Memory	<p>Supports 12 memory modules of the following types:</p> <ul style="list-style-type: none">• Up to 12 DDR4 memory modules• Max. 2933 MT/s memory speed• RDIMM and LRDIMM support• The DDR4 memory modules of different types (RDIMM and LRDIMM) and specifications (capacity, bit width, rank, and height) cannot be used together. <p>NOTE The preceding information is for reference only. Use the Intelligent Computing Compatibility Checker to obtain specific information.</p>

Category	Specifications
Storage	<p>Supports a variety of drive configurations. For details, see Drive Configurations.</p> <ul style="list-style-type: none"> Supports two M.2 SSDs. <p>NOTE</p> <ul style="list-style-type: none"> The M.2 SSD module is used only as the boot device when the OS is installed. Small-capacity (32 GB or 64 GB) M.2 SSDs do not support logging due to poor endurance. If a small-capacity M.2 SSD is used as the boot device, a dedicated log drive or log server is required for logging. For example, you can dump VMware logs in either of the following ways: <ul style="list-style-type: none"> Redirect <code>/scratch</code>. For details, see https://kb.vmware.com/s/article/1033696. Configure syslog. For details, see https://kb.vmware.com/s/article/2003322. The M.2 SSD cannot be used to store data due to poor endurance. In write-intensive applications, the M.2 SSD will wear out in a short time. Use enterprise-level high endurance (HE) SSDs or HDDs for data storage. The M.2 SSD is not recommended for write-intensive service software due to poor endurance. Do not use the M.2 SSD as the cache. <ul style="list-style-type: none"> Supports hot swap of SAS/SATA/NVMe drives. <p>NOTE The NVMe drives support:</p> <ul style="list-style-type: none"> Surprise hot swap if the VMD function is enabled and the latest Intel VMD driver is installed. Orderly hot swap if the VMD function is disabled. <ul style="list-style-type: none"> Supports a variety of RAID controller cards. Use the Intelligent Computing Compatibility Checker to obtain information about the specific RAID controller cards supported. <ul style="list-style-type: none"> The RAID controller card supports RAID configuration, RAID level migration, and drive roaming. The RAID controller card occupies one standard PCIe slot. For details about the RAID controller card, see Huawei V5 Server RAID Controller Card User Guide. Supports the 24-port SAS HBA card to improve storage performance and data security. <p>NOTE If the BIOS is in legacy mode, the 4K drive cannot be used as the boot drive.</p>

Category	Specifications
Network ports	<p>Supports expansion capability of multiple types of networks.</p> <ul style="list-style-type: none"> ● LOM <ul style="list-style-type: none"> - Supports two 10GE optical ports and two GE electrical ports via the NIC chip integrated on the mainboard. - The LOM ports support NC-SI, WOL, and PXE. ● OCP 2.0 mezzanine card <ul style="list-style-type: none"> - Supports on-demand configuration. - Supports a full range of OCP 2.0 mezzanine cards. Use the Intelligent Computing Compatibility Checker to obtain information about the specific OCP 2.0 cards supported.
I/O expansion	<p>5 PCIe 3.0 slots:</p> <ul style="list-style-type: none"> ● One slot dedicated for an OCP 2.0 mezzanine card and four for standard PCIe cards. For details, see PCIe Slots and PCIe Slot Description. <p>NOTE The preceding information is for reference only. Use the Intelligent Computing Compatibility Checker to obtain specific information.</p>
Ports	<p>Supports a variety of ports.</p> <ul style="list-style-type: none"> ● Ports on the front panel: <ul style="list-style-type: none"> - Two USB 3.0 ports - One DB15 VGA port ● Ports on the rear panel: <ul style="list-style-type: none"> - Two USB 3.0 ports - One DB15 VGA port - One RJ45 serial port - One RJ45 system management port - Two GE electrical ports - Two 10GE optical ports ● Built-in port: <ul style="list-style-type: none"> - One USB 3.0 port <p>NOTE You are not advised to install the operating system on a USB flash drive.</p>

Category	Specifications
Video card	<p>An SM750 video chip with 32 MB display memory is integrated on the mainboard. The maximum display resolution is 1920 x 1200 at 60 Hz with 16 M colors.</p> <p>NOTE</p> <ul style="list-style-type: none"> The integrated video card can provide the maximum display resolution (1920 x 1200) only after the video card driver matching the operating system version is installed. Otherwise, only the default resolution supported by the operating system is provided. If the chassis provides the front and rear VGA ports, the front VGA port is connected to a monitor by default.
System management	<ul style="list-style-type: none"> UEFI iBMC NC-SI Integration with third-party management systems
Security features	<ul style="list-style-type: none"> Power-on password Administrator password TCM (only in China)/TPM Secure boot

6.2 Environmental Specifications

Table 6-2 Environmental specifications

Category	Specifications
Temperature	<ul style="list-style-type: none"> Operating temperature: 5°C to 35°C (41°F to 95°F) (ASHRAE Class A2 compliant) Storage temperature (≤ 72 hours): -40°C to +65°C (-40°F to +149°F) Long-term storage temperature (> 72 hours): 21°C to 27°C (69.8°F to 80.6°F) Maximum temperature change rate: 20°C/h (36°F/h) <p>NOTE The highest operating temperature varies depending on the configuration. For details, see Operating Temperature Limitations.</p>
Relative humidity (RH, non-condensing)	<ul style="list-style-type: none"> Operating humidity: 8% to 90% Storage humidity (≤ 72 hours): 5% to 95% Long-term storage humidity (> 72 hours): 30% to 69% Maximum change rate: 20%/h

Category	Specifications
Air volume	≥110CFM
Altitude	<ul style="list-style-type: none"> ● Operating altitude ≤ 3050 m (10006.44 ft) If the server complying with ASHRAE Class A2 is used in a place above 900 m (2952.76 ft), the highest operating temperature decreases by 1°C (1.8°F) for every increase of 300 m (984.24 ft). ● HDDs cannot be used at an altitude of over 3000 m (9842.4 ft).
Corrosive gaseous contaminant	Maximum corrosion product thickness growth rate: <ul style="list-style-type: none"> ● Copper corrosion rate test: 300 Å/month (meeting level G1 requirements of the ANSI/ISA-71.04-2013 standard on gaseous corrosion) ● Silver corrosion rate test: 200 Å/month
Particle contaminant	<ul style="list-style-type: none"> ● The equipment room environment meets the requirements of ISO 14664-1 Class 8. ● There is no explosive, conductive, magnetic, or corrosive dust in the equipment room. <p>NOTE It is recommended that the particulate pollutants in the equipment room be monitored by a professional organization.</p>
Acoustic noise	The declared A-weighted sound power levels (LWAd) and declared average bystander position A-weighted sound pressure levels (LpAm) listed are measured at 23°C (73.4°F) in accordance with ISO 7779 (ECMA 74) and declared in accordance with ISO 9296 (ECMA 109). <ul style="list-style-type: none"> ● Idle: <ul style="list-style-type: none"> - LWAd: 6.7 Bels - LpAm: 52.9 dBA ● Operating: <ul style="list-style-type: none"> - LWAd: 6.9 Bels - LpAm: 55.6 dBA <p>NOTE Actual sound levels generated during operation vary depending on server configuration, load, and ambient temperature.</p>

6.3 Physical Specifications

Table 6-3 Physical specifications

Category	Specifications
Dimensions (H x W x D)	86.1 mm x 447 mm x 890 mm (3.39 in. x 17.60 in. x 35.04 in.)
Installation space	<ul style="list-style-type: none"> • Requirements for cabinet installation: Cabinet compliant with the International Electrotechnical Commission (IEC) 297 standard <ul style="list-style-type: none"> - Cabinet width: 482.6 mm (19 in.) - Cabinet depth ≥ 1100 mm (43.31 in.) • Requirements for guide rail installation: <ul style="list-style-type: none"> - Static rail kit: applies to cabinets with a distance of 543.5 mm to 848.5 mm (21.40 in. to 33.41 in.) between the front and rear mounting bars.
Weight in full configuration	<ul style="list-style-type: none"> • Maximum net weight: <ul style="list-style-type: none"> - Server with 24 x 3.5" drives: 50 kg (110.25 lb) Full configuration: 24 x 3.5" front drives + 4 x 2.5" rear drives + 2 x M.2 SSDs • Packaging materials: 5 kg (11.03 lb)
Power consumption	The power consumption varies depending on the server configuration. Use the Huawei Server Power Calculator to calculate the power consumption.

7 Software and Hardware Compatibility

Use the [Intelligent Computing Compatibility Checker](#) to obtain information about the operating systems and hardware supported.

NOTICE

Do not use incompatible components. Otherwise, the server may fail to work properly. The technical support and warranty do not cover faults caused by incompatible components.

8 Safety Instructions

[8.1 Safety Instructions](#)

[8.2 Maintenance and Warranty](#)

8.1 Safety Instructions


General Instructions

- Comply with all local laws and regulations when installing the hardware. The safety instructions in this document are only supplemental to local laws and regulations.
- The "DANGER", "WARNING", and "CAUTION" information in this document does not represent all the safety instructions, but supplements to the safety instructions.
- To ensure safety when installing hardware, follow all safety instructions provided on the device labels and in this document.
- Only qualified personnel are allowed to perform special tasks, such as performing high-voltage operations and driving a forklift.
- Take protective measures if a Class A product is used in residential areas as it is likely to cause radio interference.

Personal Safety

- Only personnel certified or authorized by Huawei are allowed to install the hardware.
- Stop any operation that may cause personal injury or equipment damage, report the problem to a project supervisor immediately, and take protective measures.
- Do not operate the product or handle cables during thunderstorms.
- Before carrying devices, note the following points:
 - Do not carry more weight than is permitted by local laws or regulations.
 - Ensure that there are enough people to carry the devices.
- Wear clean protective gloves, ESD clothing, a protective hat, and protective shoes, as shown in [Figure 8-1](#).

Figure 8-1 Protective clothing



- Before touching a device, ensure that you are wearing ESD clothing and ESD gloves (or wrist strap), and remove any conductive objects (such as watches and jewelry). **Figure 8-2** shows conductive objects that must be removed before you touch a device.


Figure 8-2 Conductive objects to be removed



Figure 8-3 shows how to wear an ESD wrist strap.

- Secure the ESD wrist strap around your wrist.
- Fasten the strap buckle and ensure that the ESD wrist strap is in contact with your skin.
- Insert the ground terminal attached to the ESD wrist strap into the jack on the grounded rack or chassis.

Figure 8-3 Wearing an ESD wrist strap



- Exercise caution when using tools that could cause personal injury.
- If the installation position of the device is above shoulder height, use a stacker to lift it. This will prevent it from falling.
- To prevent electric shock, do not touch high-voltage cables directly or indirectly. A high-voltage power supply may be powering the device.
- Properly ground a device before powering it on.
- Do not use a ladder alone. Have someone else hold the ladder steady to prevent accidents.
- To avoid damaging your eyes when installing, testing, or replacing optical cables, do not look into optical ports without eye protection.

Equipment Safety

- Use the recommended power cables at all times.
- Always use the power cables delivered with the devices.
- Wear ESD clothing and gloves before handling a device. This prevents electrostatic damage.
- When moving a device, hold the bottom of the device. Do not hold the handles of the installed modules, such as the PSUs, fan modules, drives, and the mainboard. Handle the equipment with care.
- Exercise caution when using tools that could cause personal injury.
- Connect the primary and secondary power cables to different power distribution units (PDUs) to ensure reliable system operation.
- Properly ground a device before powering it on.

Transportation Precautions

Improper transportation may damage equipment. Contact the manufacturer for precautions before attempting transportation.

Exercise caution when transporting equipment.

- The logistics company engaged to transport the equipment must be reliable and comply with international standards for transporting electronics. Ensure that the equipment being transported is always upright. Take necessary precautions to prevent collisions, corrosion, package damage, damp conditions and pollution.
- Transport the equipment in its original packaging.

- If the original packaging is unavailable, package heavy, bulky parts (such as chassis and blades) and fragile parts (such as PCIe GPUs and SSDs) separately.

 **NOTE**

Use [Intelligent Computing Compatibility Checker](#) to obtain information about the components supported by a node or server.

- Ensure that all devices are powered off before transportation.

Limits for the Maximum Weight Carried Per Person

 **CAUTION**

To reduce the risk of personal injury, comply with local regulations with regard to the maximum weight one person is permitted to carry.

Table 8-1 lists the maximum weight one person is permitted to carry as stipulated by a number of organizations.

Table 8-1 Maximum weight one person is permitted to carry

Organization	Weight (kg/lb)
European Committee for Standardization (CEN)	25/55.13
International Organization for Standardization (ISO)	25/55.13
National Institute for Occupational Safety and Health (NIOSH)	23/50.72
Health and Safety Executive (HSE)	25/55.13
General Administration of Quality Supervision, Inspection and Quarantine of the People's Republic of China (AQSIQ)	<ul style="list-style-type: none"> • Men: 15/33.08 • Women: 10/22.05

For more information about security instructions, see [Huawei Server Safety Information](#).

8.2 Maintenance and Warranty

For details about the maintenance and warranty, see [Maintenance & Warranty](#).

9 System Management

The server uses Huawei proprietary intelligent Baseboard Management Controller (iBMC) to implement remote server management. The iBMC complies with Intelligent Platform Management Interface (IPMI) 2.0 and provides highly reliable hardware monitoring and management.

Features

The iBMC supports the following features and protocols:

- KVM and text console redirection
- Remote virtual media
- IPMI
- SNMP
- Common information model (CIM)
- Redfish
- Browser-based login

Specifications

Table 9-1 iBMC specifications

Feature	Description
Management interface	Integrates with any standard management system through the following interfaces or protocols: <ul style="list-style-type: none">• IPMI• CLI• HTTPS• SNMP• Redfish
Fault detection	Detects and accurately locates faults in hardware, for example, an FRU.

Feature	Description
System watchdog	Supports BIOS POST, OS watchdog, and automatic system reset after fault timeout. Users can enable or disable these features individually.
Boot device configuration	Supports out-of-band configuration for boot devices.
Alarm management	Supports alarm management and reports alarms using the SNMP trap, Simple Mail Transfer Protocol (SMTP), and syslog service to ensure 24/7 operating.
Integrated virtual KVM	Provides remote maintenance measures and VNC service for troubleshooting.
Integrated virtual media	Virtualizes local media devices, images, USB keys, and folders into media devices on a remote server, simplifying OS installation. (The virtual DVD drive supports a maximum transmission rate of 8 MB/s.)
WebUI	Provides a user-friendly graphical user interface (GUI), simplifying user configuration and query operations.
Fault reproduction	Reproduces faults to help diagnose them quickly.
Screen snapshots and screen videos	Allows users to view screenshots and videos without login, facilitating routine preventive maintenance inspection (PMI).
Black Box	Allows users to enable or disable the black box function and download black box data.
DNS/LDAP	Supports domain management and directory services, significantly simplifying network and configuration management.
Dual-image backup	If iBMC software fails, it starts again from a backup image.
Asset management	Supports intelligent asset management.
Intelligent power management	Uses power capping to increase deployment density, and uses dynamic energy saving to reduce operating expenditure.
IPv6	Supports IPv6 to ensure sufficient IP addresses.
Network Controller Sideband Interface (NC-SI)	Supports NC-SI, allowing access the iBMC through the service network port.

10 Certifications

Country/Region	Certification	Standards
China	CCC	GB4943.1-2011 GB9254-2008(Class A) GB17625.1-2012

A Appendix

A.1 Product SN

The serial number (SN) on the slide-out label plate uniquely identifies a device. The SN is required when you contact Huawei technical support.

Figure A-1 SN example



Table A-1 SN description

Callout No.	Description
1	SN ID (two characters), which is 21 .
2	Material identification code (8 characters), that is, the processing code.
3	Vendor code (two characters). 10 indicates Huawei, and other values indicate outsourcing vendors.

Callout No.	Description
4	Year and month (two characters). <ul style="list-style-type: none"> • The first character indicates the year. <ul style="list-style-type: none"> - Digits 1 to 9 indicate years 2001 to 2009, respectively. - Letters A to H indicate years 2010 to 2017, respectively. - Letters J to N indicate years 2018 to 2022, respectively. - Letters P to Y indicate years 2023 to 2032, respectively. <p>NOTE The years from 2010 are represented by uppercase letters excluding I, O, and Z because the three letters are similar to digits 1, 0, and 2.</p> <ul style="list-style-type: none"> • The second character indicates the month. <ul style="list-style-type: none"> - Digits 1 to 9 indicate January to September, respectively. - Letters A to C indicate October to December, respectively.
5	Sequence number (six characters).
6	RoHS compliance (one character). Y indicates RoHS compliant.
7	Internal model, that is, product name.

A.2 Operating Temperature Limitations

Table A-2 Operating temperature limitations

Configuration	Max. 30°C (86°F)	Max. 35°C (95°F)
24 x 3.5" drive configuration	<ul style="list-style-type: none"> • All options supported 	<ul style="list-style-type: none"> • All options supported

A.3 RAS Features

The server supports a variety of Reliability, Availability, and Serviceability (RAS) features. You can configure these features for better RAS.

For details about how to configure RAS features, see [Huawei Server Purley Platform BIOS Parameter Reference](#).

Table A-3 RAS features

Module	Feature	Description
CPU	Corrected Machine Check Interrupt	Corrects error-triggered interruption.
DIMM	Failed DIMM Isolation	Identifies a faulty DIMM and isolates it from others before it is replaced.

Module	Feature	Description
	Memory Thermal Throttling	Automatically adjusts DIMM temperatures to avoid damage due to overheating.
	Rank Sparing	Allocates some memory ranks as backup ranks to prevent the system from crashing due to uncorrectable errors.
	Memory Address Parity Protection	Detects memory command and address errors.
	Memory Demand and Patrol Scrubbing	Corrects errors upon detection. If these errors are not corrected promptly, uncorrectable errors may occur.
	Memory Mirroring	Improves system reliability.
	Single Device Data Correction	Provides a single-device multi-bit error correction capability to improve memory reliability.
	Device Tagging	Degrades and rectifies DIMM device faults to improve DIMM availability.
	Data Scrambling	Optimizes data stream distribution and reduces the error possibility to improve the reliability of data streams in the memory and the capability to detect address errors.
PCIe	PCIe Advanced Error Reporting	Improves server serviceability.
UPI	Intel UPI Link Level Retry	Provides a retry mechanism upon errors to improve UPI reliability.
	Intel UPI Protocol Protection via CRC	Provides cyclic redundancy check (CRC) protection for UPI packets to improve system reliability.
System	Core Disable for Fault Resilient Boot (FRB)	Isolates a faulty CPU core during startup to improve system reliability and availability.
	Corrupt Data Containment Mode	Identifies the memory storage unit that contains corrupted data to minimize the impact on the running programs and improve system reliability.
	Socket disable for Fault Resilient Boot (FRB)	Isolates a faulty socket during the BIOS startup process to improve system reliability.

Module	Feature	Description
	Architected Error Records	With the enhanced machine check architecture (eMCA) feature, the BIOS collects error information from hardware registers in compliance with UEFI specifications, sends the error information to the OS over the APEI of the Advanced Configuration and Power Interface (ACPI), and locates the error unit, improving system availability.
	Error Injection Support	Injects errors to verify various RAS features.
	Machine Check Architecture	Provides software recovery for uncorrectable errors to improve system availability.
	eMCA: Gen2	Improves system availability.
	OOB access to MCA registers	The OBB system accesses MCA registers by using the Platform Environment Control Interface (PECI). If a fatal error occurs in the system, the out-of-band system collects onsite data to facilitate fault analysis and locating and improve system serviceability.
	BIOS Abstraction Layer for Error Handling	The BIOS processes errors and reports the error information to the OS and the server in compliance with specifications to improve system serviceability.
	BIOS-based Predictive Failure Analysis (PFA)	The BIOS provides physical unit information for DIMM errors, and the OS traces and predicts errors, and isolates error memory pages.

A.4 Sensor List

Sensor	Description	Component
Inlet Temp	Air inlet temperature	Left mounting ear
Outlet Temp	Air outlet temperature	Mainboard
PCH Temp	PCH bridge temperature	Mainboard

Sensor	Description	Component
CPU N Core Rem	CPU core temperature	CPU N N indicates the CPU number. The value is 1 or 2 .
CPU N DTS	CPU DTS value	CPU N N indicates the CPU number. The value is 1 or 2 .
CPU N Margin	CPU Margin	CPU N N indicates the CPU number. The value is 1 or 2 .
CPU N VDDQ Temp	CPU VDDQ temperature	Mainboard N indicates the CPU number. The value is 1 or 2 .
CPU N VRD Temp	CPU VRD temperature	Mainboard N indicates the CPU number. The value is 1 or 2 .
CPU N MEM Temp	CPU DIMM temperature	DIMMs of CPU N N indicates the CPU number. The value is 1 or 2 .
SYS 3.3V	Mainboard 3.3 V voltage	Mainboard
SYS 5V	Mainboard 5.0 V voltage	Mainboard
SYS 12V_1	Mainboard 12.0 V voltage	Mainboard
SYS 12V_2	Mainboard 12.0 V voltage	Mainboard
CPU N VCore	1.8 V CPU voltage	Mainboard N indicates the CPU number. The value is 1 or 2 .
CPU N DDR VDDQ	1.2 V DIMM voltage	Mainboard N indicates the CPU number. The value is 1 or 2 .

Sensor	Description	Component
CPU/ <i>N</i> DDR VDDQ2	1.2 V DIMM voltage	Mainboard <i>N</i> indicates the CPU number. The value is 1 or 2 .
CPU/ <i>N</i> VSA	CPU VSA voltage	Mainboard <i>N</i> indicates the CPU number. The value is 1 or 2 .
CPU/ <i>N</i> VCCIO	CPU VCCIO voltage	Mainboard <i>N</i> indicates the CPU number. The value is 1 or 2 .
CPU/ <i>N</i> VMCP	CPU VMCP voltage	Mainboard <i>N</i> indicates the CPU number. The value is 1 or 2 .
PCH VPVNN	PCH VPVNN voltage	Mainboard
PCH PRIM 1V05	PCH PRIM voltage	Mainboard
HDD BP/ <i>N</i> STBY3.3V	Drive backplane 3.3 V voltage	Front-drive backplane <i>N</i> indicates the backplane number. The value is 1 or 2 .
HDD BP/ <i>N</i> 5V	Drive backplane 5.0 V voltage	Front-drive backplane <i>N</i> indicates the backplane number. The value is 1 or 2 .
HDD BP/ <i>N</i> 12V	Drive backplane 12.0 V voltage	Front-drive backplane <i>N</i> indicates the backplane number. The value is 1 or 2 .
CPU/ <i>N</i> VCCP	CPU VCCP voltage	Mainboard
CPU/ <i>N</i> DDR VPP1	CPU DDR voltage	Mainboard
CPU/ <i>N</i> DDR VPP2	CPU DDR voltage	Mainboard
FAN/ <i>N</i> Speed	Fan speed	Fan module/ <i>N</i> <i>N</i> indicates the fan module number. The value ranges from 1 to 5 .
Power	Server input power	PSUs

Sensor	Description	Component
PSU/VIN	Input voltage of PSU <i>N</i>	PSU <i>N</i> <i>N</i> indicates the PSU number. The value is 1 or 2 .
Disks Temp	Maximum temperature of SAS/SATA drives	SAS/SATA drives
Power/ <i>N</i>	PSU input power	PSU <i>N</i> <i>N</i> indicates the PSU number. The value is 1 or 2 .
PCH Status	PCH chip fault diagnosis health status	Mainboard
CPU <i>N</i> QPI Link	CPU QPI link fault diagnosis health status	Mainboard or CPU <i>N</i> <i>N</i> indicates the CPU number. The value is 1 or 2 .
CPU <i>N</i> Prochot	CPU Prochot	CPU <i>N</i> <i>N</i> indicates the CPU number. The value is 1 or 2 .
System Error	System suspension or restart. Check the background logs	Mainboard
CPU <i>N</i> Status	CPU status	CPU <i>N</i> <i>N</i> indicates the CPU number. The value is 1 or 2 .
CPU <i>N</i> Memory	CPU memory status	DIMMs of CPU <i>N</i> <i>N</i> indicates the CPU number. The value is 1 or 2 .
FAN <i>N</i> Status	Fan status	Fan module <i>N</i> <i>N</i> indicates the fan module number. The value ranges from 1 to 5 .
DIMM <i>N</i>	DIMM status	DIMM <i>N</i> <i>N</i> indicates the DIMM slot number.

Sensor	Description	Component
RTC Battery	RTC battery status. An alarm is generated when the voltage is lower than 1 V.	RTC battery
PCIE Status	PCIe status	PCIe cards
ACPI State	ACPI status	Mainboard
Power Button	Power button pressed state	Mainboard and power button
Watchdog2	Watchdog	Mainboard
Mngmnt Health	Management subsystem health status	Management modules
UID Button	UID button status	Mainboard
PwrOk Sig. Drop	Voltage dip status	Mainboard
PwrOn TimeOut	Power-on timeout	Mainboard
PwrCap Status	Power capping status	Mainboard
HDD Backplane	Entity presence	Drive backplane
HDD BP Status	Drive backplane health status	Drive backplane
Riser1 Card	Entity presence	Riser card
SAS Cable	Entity presence	SAS cable on the mainboard
FAN <i>N</i> Presence	Fan presence	Fan module <i>N</i> <i>N</i> indicates the fan module number. The value ranges from 1 to 5 .
RAID Presence	RAID controller card presence	RAID controller card
PS Redundant	Redundancy failure due to PSU removal	PSUs
NIC# Status	NIC fault diagnosis health status	LOM
PS <i>N</i> Status	PSU status	PSU <i>N</i> <i>N</i> indicates the PSU number. The value is 1 or 2 .

Sensor	Description	Component
PSN Fan Status	PSU fan status	PSU/N N indicates the PSU number. The value is 1 or 2.
PSN Temp Status	PSU presence	PSU/N N indicates the PSU number. The value is 1 or 2.
DISK/N	Drive status	Drive/N N indicates the drive slot number. The value ranges from 0 to 27.
M2Disk/N	Status of the M.2 drives on the riser card	M.2 drives on the riser card
Port/N Link Down	LOM	LOM
PCIe RAID\$ Temp	PCIe RAID controller card temperature	PCIe RAID controller card
RAID Temp	RAID controller card temperature	RAID controller card
RAID Status	RAID controller card health status	RAID controller card
RAID PCIE ERR	RAID controller card fault diagnosis health status	RAID controller card
IB\$ TEMP	IB adapter temperature	IB adapter
RAID Card BBU	RAID controller card BBU	BBU supercapacitor of RAID controller card
PS\$ Inlet Temp	PSU air inlet temperature	PSUs
OCP1 OP Temp	OCP 2.0 mezzanine card optical module temperature	OCP 2.0 mezzanine card optical module temperature
OCP1 Temp	OCP 2.0 mezzanine card chip temperature	OCP 2.0 mezzanine card chip temperature

B Glossary

B.1 A-E

B

baseboard management controller (BMC)	The BMC complies with the Intelligent Platform Management Interface (IPMI). It collects, processes, and stores sensor signals, and monitors the operating status of components. The BMC provides the hardware status and alarm information about the managed objects to the upper-level management system, so that the management system can manage the objects.
--	--

E

ejector lever	A part on the panel of a device used to facilitate installation or removal of the device.
Ethernet	A baseband local area network (LAN) architecture developed by Xerox Corporation by partnering with Intel and DEC. Ethernet uses the Carrier Sense Multiple Access/Collision Detection (CSMA/CD) access method and allows data transfer over various cables at 10 Mbit/s. The Ethernet specification is the basis for the IEEE 802.3 standard.

B.2 F-J

G

Gigabit Ethernet (GE)	An extension and enhancement of traditional shared media Ethernet standards. It is compatible with 10M and 100M Ethernet and complies with IEEE 802.3z standards.
------------------------------	---

H

hot swap	Replacing or adding components without stopping or shutting down the system.
-----------------	--

B.3 K-O

K

KVM	A hardware device that provides public keyboard, video and mouse (KVM).
------------	---

M

mezzanine card	A board, parallel to the mainboard and connected to the mainboard through connectors, used to improve space utilization in a chassis.
-----------------------	---

B.4 P-T

P

panel	An external component (including but not limited to ejector levers, indicators, and ports) on the front or rear of the server. It seals the front and rear of the chassis to ensure optimal ventilation and electromagnetic compatibility (EMC).
--------------	--

Peripheral Component Interconnect Express (PCIe)	A computer bus PCI, which uses the existing PCI programming concepts and communication standards, but builds a faster serial communication system. Intel is the main sponsor for PCIe. PCIe is used only for internal interconnection. A PCI system can be transformed to a PCIe one by modifying the physical layer instead of software. PCIe delivers a faster speed and can replace almost all AGP and PCI buses.
---	--

R

redundancy	A mechanism that allows a backup device to automatically take over services from a faulty device to ensure uninterrupted running of the system.
redundant array of independent disks (RAID)	A storage technology that combines multiple physical drives into a logical unit for the purposes of data redundancy and performance improvement.

S

server	A special computer that provides services for clients over a network.
system event log (SEL)	A non-volatile area and interfaces used to store system events for later fault diagnosis and system recovery.

B.5 U-Z

U

U	A unit defined in International Electrotechnical Commission (IEC) 60297-1 to measure the height of a cabinet or chassis. 1 U = 44.45 mm
UltraPath Interconnect (UPI)	A point-to-point processor interconnect developed by Intel.

C Acronyms and Abbreviations

C.1 A-E

A

AC	alternating current
AES	Advanced Encryption Standard New Instruction Set
ARP	Address Resolution Protocol
AVX	Advanced Vector Extensions

B

BBU	backup battery unit
BIOS	Basic Input/Output System
BMC	baseboard management controller

C

CD	calendar day
CE	Conformite Europeenne
CIM	Common Information Model
CLI	command-line interface

D

DC	direct current
DDR3	double data rate 3
DDR4	double data rate 4
DDDC	double device data correction
DEMT	Dynamic Energy Management Technology
DIMM	dual in-line memory module
DRAM	dynamic random-access memory
DVD	digital video disc

E

ECC	error checking and correcting
ECMA	European Computer Manufacturer Association
EDB	Execute Disable Bit
EN	European Efficiency
ERP	enterprise resource planning
ETS	European Telecommunication Standards

C.2 F-J

F

FB-DIMM	Fully Buffered DIMM
FC	Fiber Channel
FCC	Federal Communications Commission
FCoE	Fibre Channel over Ethernet
FTP	File Transfer Protocol

G

GE	Gigabit Ethernet
-----------	------------------

GPIO	General Purpose Input/Output
GPU	graphics processing unit

H

HA	high availability
HDD	hard disk drive
HPC	high-performance computing
HTTP	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure

I

iBMC	intelligent baseboard management controller
IC	Industry Canada
ICMP	Internet Control Message Protocol
IDC	Internet Data Center
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Message Protocol
IOPS	input/output operations per second
IP	Internet Protocol
IPC	intelligent power capability
IPMB	Intelligent Platform Management Bus
IPMI	Intelligent Platform Management Interface

C.3 K-O

K

KVM	keyboard, video, and mouse
------------	----------------------------

L

LC	Lucent connector
LRDIMM	load-reduced dual in-line memory module
LED	light emitting diode
LOM	LAN on motherboard

M

MAC	media access control
MMC	module management controller

N

NBD	next business day
NC-SI	Network Controller Sideband Interface

C.4 P-T**P**

PCIe	Peripheral Component Interconnect Express
PDU	power distribution unit
PHY	physical layer
PMBUS	power management bus
POK	power OK
PWM	pulse-width modulation
PXE	Preboot Execution Environment

Q

QPI	Quick Path Interconnect
------------	-------------------------

R

RAID	redundant array of independent disks
RAS	reliability, availability and serviceability
RDIMM	registered dual in-line memory module
REACH	Registration Evaluation and Authorization of Chemicals
RJ45	registered jack 45
RoHS	Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment

S

SAS	Serial Attached Small Computer System Interface
SATA	Serial Advanced Technology Attachment
SCM	supply chain management
SDDC	single device data correction
SERDES	serializer/deserializer
SGMII	serial gigabit media independent interface
SMI	serial management interface
SMTP	Simple Mail Transfer Protocol
SNMP	Simple Network Management Protocol
SOL	serial over LAN
SONCAP	Standards Organization of Nigeria-Conformity Assessment Program
SSD	solid-state drive
SSE	Streaming SIMD Extensions

T

TACH	tachometer signal
TBT	Turbo Boost Technology
TCG	Trusted Computing Group
TCM	trusted cryptography module
TCO	total cost of ownership

TDP	thermal design power
TELNET	Telecommunication Network Protocol
TET	Trusted Execution Technology
TFM	TransFlash module
TFTP	Trivial File Transfer Protocol
TOE	TCP offload engine
TPM	trusted platform module

C.5 U-Z

U

UDIMM	unbuffered dual in-line memory module
UEFI	Unified Extensible Firmware Interface
UID	unit identification light
UL	Underwriter Laboratories Inc.
USB	Universal Serial Bus

V

VCCI	Voluntary Control Council for Interference by Information Technology Equipment
VGA	Video Graphics Array
VLAN	virtual local area network
VRD	voltage regulator-down

W

WEEE	waste electrical and electronic equipment
WSMAN	Web Service Management